



---

DIGITAL SIGNAL PROCESSING

# T/X-DDC/AFE

RF Amplifier for Digital Radio Receiver DCM

## User's Guide

covers:  
T/X-DDC/AFE rev.1A

**MicroLAB Systems Ltd**

59a Beskudnikovsky blvd, 127486, Moscow, RUSSIA

phone/fax: +7-(095)-485-6332 Email: [info@mlabsys.com](mailto:info@mlabsys.com) WWW: [www.mlabsys.com](http://www.mlabsys.com)

## **CAUTION**

Фирма *МикроЛАБ Системс Лтд (МЛС)* оставляет за собой право вносить любые изменения и прекращать выпуск и поддержку любых изделий и программного обеспечения, упоминаемых в настоящем документе, без какого-либо предварительного уведомления, если иное специально не оговаривается. *МЛС* рекомендует своим покупателям пользоваться подлинными и самыми последними версиями фирменных информационных документов и осуществлять предварительное консультирование с фирмой перед размещением заказа, чтобы быть уверенным, что настоящая информация достоверна и применима на текущий момент.

*МЛС* гарантирует качество и соответствие технических параметров поставляемой продукции приведенной технической спецификации. Всякое тестирование и проверка продукции производится фирмой в степени и объемах, необходимых для поддержки настоящей гарантии. Какое-либо дополнительное тестирование и проверка продукции на соответствие другим требованиям проводятся лишь и только в случаях, выполняемых по специальному заказам, или тогда, когда это специально оговаривается.

*МЛС* не несет никакой ответственности за правильность функционирования и работоспособность оборудования и программного обеспечения, разработанного и изготовленного с применением продукции (или отдельных ее компонентов) фирмы, если это не подтверждено специальным фирменным сертификатом *МЛС*.

Продукция *МЛС* не предназначена для применения в аппаратуре, системах или изделиях для поддержки жизнедеятельности. Применение продукции *МЛС* в таком оборудовании категорически запрещено без специального письменного подтверждения от *МЛС* или оригинального фирменного сертификата *МЛС*.

## **IMPORTANT NOTICE**

Настоящая продукция предназначена для использования в составе лабораторного тестового и научно-исследовательского оборудования. *МЛС* не несет ответственности за работоспособность настоящей продукции в составе другого типа оборудования и/или в отличных от специфицированных условиях эксплуатации. При повреждениях настоящей продукции, вызванных ее применением в составе другого типа оборудования и/или условий эксплуатации, гарантийные обязательства аннулируются без какого-либо возмещения ущерба и ремонт производится за счет покупателя.

Настоящая продукция генерирует, использует и может излучать радиочастотную энергию, которая может создавать радиочастотные помехи для другой аппаратуры, несмотря на все конструктивные и другие меры, предпринятые для минимизации создаваемых помех. Однако, в случае возникновения помех для работы другой аппаратуры покупатель должен сам и за свой счет принять меры для их устранения или уменьшения.

## **ITEMS OF LICENSE AGREEMENT**

Никакие части настоящего документа, аппаратные и программные части настоящей продукции не могут быть реассемблированы, ретарсированы и/или изменены с целью восстановления и/или изменения электрической схемы, конструкции, алгоритма работы или принципа функционирования любыми методами, воспроизведены, скопированы, запомнены в архивах с возможностью воспроизведения, а также переданы по средствам связи в любом виде и любыми методами, будь то электронные, механические, копировальные, фотографические, записывающие или другие, без предварительно выданного фирменного письменного разрешения от *МЛС*. Нарушение настоящего положения вне зависимости от приобретения настоящей продукции и/или документа трактуется как нарушение авторских прав и преследуется по закону.

Приобретение настоящей продукции автоматически означает согласие покупателя с положениями лицензионного соглашения, равно как и другими положениями закона об авторских правах. Нарушение настоящих положений, равно как и других положений закона об авторских правах, трактуется как нарушение авторских прав, преследуется по закону и автоматически ведет к аннулированию всех обязательств *МЛС* по поддержке настоящей продукции.

Copyright © 1993-2000, MicroLAB Systems Ltd. All rights reserved.

## About this Document

This user's guide contains description for *T/X-DDC/AFE* external RF amplifier for digital radio receiver DCM for *TORNADO* DSP systems/controllers/coprocessors from MicroLAB Systems Ltd.

This document does not include detail description neither for *TORNADO* systems, nor for TI DSP and corresponding software and hardware applications. To get the corresponding information please refer to the following documentation:

1. ***T/SDAS-DDC1 Digital Radio-Receiver SIOX DCM for TORNADO DSP Systems/Controllers/Coprocessors. User's Guide.*** MicroLAB Systems, 1999.
2. ***TORNADO-PX/DDC4 Quad Digital Radio-Receiver PIOX Coprocessor DCM for TORNADO DSP Systems/Controllers. User's Guide.*** MicroLAB Systems, 2000.

## Warranty

All hardware and software products purchased from MicroLAB Systems Ltd are guaranteed against damages during *one year* after shipment. MicroLAB Systems Ltd guarantees free of charge repair or replacement for the manufacturer caused damaged products during warranty period. Software updates will be also sent free of charge to the customer during warranty period.

## If you need assistance, documentation or information...

Should you need technical assistance for purchased MicroLAB Systems Ltd products or if you want to order additional documentation or get latest information about MicroLAB Systems Ltd products, please call, fax or mail to MicroLAB Systems Ltd customer support service:

<i>address:</i>	59a Beskudnikovsky blvd, 127486, Moscow, RUSSIA. <i>MicroLAB Systems Ltd</i>
<i>phone/fax:</i>	+7-(095)-485-6332
<i>information request:</i>	<a href="mailto:info@mlabsys.com">info@mlabsys.com</a>
<i>technical support:</i>	<a href="mailto:techsupport@mlabsys.com">techsupport@mlabsys.com</a>
<i>WWW:</i>	<a href="http://www.mlabsys.com">http://www.mlabsys.com</a>
<i>FTP:</i>	<a href="ftp://ftp.mlabsys.com">ftp://ftp.mlabsys.com</a>

## Trademarks

*TORNADO-3x, TORNADO-4x, TORNADO-54x, TORNADO-6x, TORNADO-PX, TORNADO-SX, TORNADO-E, TORNADO-EL, MIRAGE-510D, UECM, MX-Link* are trademarks of *MicroLAB Systems Ltd*

*TMS320, XDS510* are trademarks of *Texas Instruments Inc*

Other trademarks and company names used are trademarks of their respective holders.

# Contents

<b>Chapter 1. Introduction</b>	<b>1</b>
1.1 General Information	1
1.2 Technical Specifications	3
<b>Chapter 2. Construction</b>	<b>5</b>
2.1 Block Diagram	5
2.2 Construction	7
<b>Chapter 3. Installation</b>	<b>9</b>
3.1 Installation	9
3.2 Connection to external signal I/O equipment	9
<b>Appendix A. Connectors and Switches</b>	<b>A-1</b>
A.1 Configuration Switches	A-1
A.2 Connectors	A-1

# Figures

<i>Fig. 1-1.</i> T/X-DDC/AFE external RF amplifier.	1
<i>Fig. 1-2.</i> T/X-DDC/AFE connected to T/SDAS-DDC1 digital radio receiver DCM, which is installed onto TORNADO-E67 stand-alone DSP controller.	2
<i>Fig. 2-1.</i> Block diagram of T/X-DDC/AFE RF amplifier.	5
<i>Fig. 2-2.</i> Band-pass plot for T/X-DDC/AFE-10.7M/B330K external RF amplifier.	6
<i>Fig. 2-3.</i> Gain control plot for T/X-DDC/AFE external RF amplifier.	7
<i>Fig. A-1.</i> Connectors and configuration switches for T/X-DDC/AFE external RF amplifier.	A-1
<i>Fig. A-2.</i> Pinout for JP3 power/control connector of T/X-DDC/AFE.	A-2

## Tables

<i>Table 2-1.</i> Source gain control voltage selector for <i>T/X-DDC/AFE</i> RF amplifier.	6
<i>Table A-1.</i> Configuration switches for <i>T/X-DDC/AFE</i> module.	A-1
<i>Table A-2.</i> Connectors of <i>T/X-DDC/AFE</i> module.	A-2
<i>Table A-1.</i> Signal description for JP3 power/control connector of <i>T/X-DDC/AFE</i> .	A-2

# Chapter 1. Introduction

This chapter contains general description for *T/X-DDC/AFE* external RF amplifier.

## 1.1 General Information

*T/X-DDC/AFE* (fig.1-1) is a single-channel external RF amplifier for digital radio receiver daughter-card modules (DCM) for *TORNADO* DSP systems/controllers/coprocessors from MicroLAB Systems Ltd.



Fig. 1-1. *T/X-DDC/AFE* external RF amplifier.

### Installation

*T/X-DDC/AFE* RF amplifier connects as external device to *T/SDAC-DDC1 SIOX* digital radio receiver DCM and *TORNADO-PX/DDC4* quad-channel digital radio receiver coprocessor DCM from MicroLAB Systems Ltd. Fig.1-2 shows connection of *T/X-DDC/AFE* RF amplifier to *T/SDAC-DDC1 SIOX* DCM.




Fig. 1-2. T/X-DDC/AFE connected to T/SDAS-DDC1 digital radio receiver DCM, which is installed onto TORNADO-E67 stand-alone DSP controller.

## Overview

T/X-DDC/AFE external RF amplifier provides one channel of RF bandpass RF amplifier with internal gain control feature, which can be controlled by external DC voltage.

T/X-DDC/AFE external RF amplifier is available in a variety of off-the-shelf configurations for the band-pass and central frequency parameters. Also available are the customized bandpass and central frequency parameters for T/X-DDC/AFE external RF amplifier.

T/X-DDC/AFE external RF amplifier features externally voltage controlled gain parameter within a wide gain range. This output voltage for external gain control is available as standard from all digital radio receiver DCMs for TORNADO DSP systems/controllers/coprocessors from MicroLAB Systems Ltd.

## applications

T/X-DDC/AFE RF amplifier has been designed for IF/RF pre-amplifiers for digital radio applications using TORNADO DSP systems/controllers/coprocessors with the corresponding digital radio receiver DCM.

T/X-DDC/AFE RF amplifier can be also used as external RF amplifier option with a variety of 3<sup>rd</sup> party RF equipment.

## 1.2 Technical Specifications

The following are technical specifications for *T/X-DDC/AFE* external RF amplifier for temperature of external environment +25°C.

<i>parameter description</i>	<i>parameter value</i>
<i>RF channel:</i>	
number of I/O channels	1
input impedance for RF-IN input	50 Ohm ±5%
output impedance for RF-OUT output	50 Ohm ±5%
maximum input RF voltage range	0.5 Vrms
maximum output RF voltage range	1.4 Vrms
gain factor, controlled by external DC voltage	0dB..+80dB (log function)
external DC voltage range for gain control	0V..+4V
gain settling time within 10% accuracy	12mS typ
central frequency / bandpass configurations	10.7MHz/150kHz 10.7MHz/330kHz 10.7MHz/1MHz 10.7MHz/2MHz 10.7MHz/5MHz 21.4MHz/2MHz 21.4MHz/5MHz 21.4MHz/10MHz (customized configurations are available on request)
bandpass ripple	±3 dB typ (refer to individual certificate)
bandstop ripple	- with 160kHz bandpass: -40dB at 400kHz bandpass - with 330kHz bandpass: -40dB at 680kHz bandpass - with ≥1MHz bandpass: 36dB/octave typ (refer to individual certificate)
THD	64dB typ at 0.7Vrms output voltage
<i>physical/power</i>	

external power supply voltages	$\pm 9V.. \pm 15V$
power consumption	+12V@80mA, -12V@80mA
dimensions	2.6"x4.25"x1.12"

# Chapter 2. Construction

This chapter contains description of architecture and construction for *T/X-DDC/AFE* external RF amplifier.

## 2.1 Block Diagram

Basic configuration and connectivity of *T/X-DDC/AFE* module is presented at fig.2-1.




Fig. 2-1. Block diagram of *T/X-DDC/AFE* RF amplifier.

*T/X-DDC/AFE* RF amplifier is an external device, which connects to either of digital radio receiver DCM for *TORNADO* DSP systems/controllers/coprocessors, which are available from MicroLAB Systems Ltd.

*T/X-DDC/AFE* external RD amplifier comprises of the following components:

- PGA1/BPFD1 programmable gain amplifier and band-pass filter of stage #1
- PGA2/BPFD2 programmable gain amplifier and band-pass filter of stage #2
- OA output RF buffer, which allows 50 Ohm low-impedance loads
- JP1 and JP2 RF-IN and RF-OUT BNC connectors
- JP2 control/power connector.

### central frequency and pass

*T/X-DDC/AFE* external RF amplifier is available in a variety of off-the-shelf configurations for the band-pass and central frequency parameters, and moreover, the customized versions are also available upon request. Typical band-pass plot for *T/X-DDC/AFE-10.7M/B330K* RF amplifier with 10.7MHz central frequency and 330kHz band-pass is presented at fig.2-2.




Fig. 2-2. Band-pass plot for *T/X-DDC/AFE-10.7M/B330K* external RF amplifier.

### **gain control**

*T/X-DDC/AFE* external RF amplifier provides external voltage controlled gain within the range 0dB..+80dB. This external gain controlled voltage can be sourced from any of two AOUT-1/2 inputs of the JP3 control/power connector, which are the DC voltage outputs from the on-board DACs of digital radio receiver DCMs from MicroLAB Systems Ltd.

The particular AOUT-1/2 voltage input, which is used for gain controlled is defined by means of the on-board two-button SW1 switch in accordance with table 2-1. SW1 switch is located at the bottom of *T/X-DDC/AFE* RF amplifier box.

Table 2-1. Source gain control voltage selector for *T/X-DDC/AFE* RF amplifier.

SW-1	SW-2	description
ON	OFF	AOUT-1 DC voltage input of JP3 connector is used for gain control.
OFF	ON	AOUT-2 DC voltage input of JP3 connector is used for gain control.
OFF	OFF	No gain control is used. Gain factor is about 0dB.

Notes:

1. Shaded configuration corresponds to default factory setting.

Typical gain plot against the gain control voltage for *T/X-DDC/AFE* RF amplifier is presented at fig.2-3.




Fig. 2-3. Gain control plot for *T/X-DDC/AFE* external RF amplifier.

## 2.2 Construction

*T/X-DDC/AFE* external RF amplifier (fig.1-1) is designed in the plastic box with two-sided connectors and DIP-switch at the bottom of the box.

Connection of *T/X-DDC/AFE* external RF amplifier to external analog I/O world is performed via JP1 and JP2 RF-IN and RF-OUT industry standard BNC connectors correspondingly.

Connection of power and gain control voltage to *T/X-DDC/AFE* is performed via JP3 connector (refer to Appendix A for details).



# Chapter 3. Installation

This chapter contains information for installation and configuration of *T/X-DDC/AFE* module.

## 3.1 Installation

*T/X-DDC/AFE* external RF amplifier connects as external device to digital radio-receiver DCMs from MicroLAB Systems Ltd. Installation procedure is as easy as the following:

1. Switch off the power of host PC with *TORNADO* DSP system installed or the power of *TORNADO-E* stand-alone DSP controller.
2. Connect JP3 connector of *T/X-DDC/AFE* to the AUX I/O connector of external cable set for either *T/SDAS-DDC1* digital radio receiver SIOX DCM or *TORNADO-PX/DDC4* quad-channel digital radio receiver coprocessor DCM.
3. Connect JP2 RF-OUT BNC connector of *T/X-DDC/AFE* to the RF-AIN connector from external cable set of either *T/SDAS-DDC1* digital radio receiver SIOX DCM or *TORNADO-PX/DDC4* quad-channel digital radio receiver coprocessor DCM via the BNC-to-BNC plug converter.
4. Configure SW1 at the bottom of *T/X-DDC/AFE* in order to select the AOUT-1/2 input DC voltage of JP3 connector for gain control.
5. Connect external RF input signal to the JP1 RF-IN BNC connector of *T/X-DDC/AFE*.
6. Switch on power of host PC or of *TORNADO-E* stand-alone DSP controller.

## 3.2 Connection to external signal I/O equipment

Connection of *T/X-DDC/AFE* to external RF equipment is performed by means of JP1 BNC connector (fig.1-1 and A-1).

### CAUTION

It is highly recommended to plug-in and unplug external RF cable to JP1 RF-IN BNC connector of *T/X-DDC/AFE* when power is switched off.

The ground signal of *T/X-DDC/AFE* has no halvanic isolation from host *TORNADO* and/or PC ground signal and chassis.



# Appendix A. Connectors and Switches

This appendix contains a summary for connectors and configuration switches for *T/X-DDC/AFE* external RF amplifier.

Connectors and configuration switches *T/X-DDC/AFE* external RF amplifier are presented at fig.A-1.




Fig. A-1. Connectors and configuration switches for *T/X-DDC/AFE* external RF amplifier.

## A.1 Configuration Switches

Table A-1 specifies the list of configuration switches for *T/X-DDC/AFE* external RF amplifier.

Table A-1. Configuration switches for *T/X-DDC/AFE* module.

Switch	description	Reference information
SW1	Source DC voltage selector for gain control. This switch is located at the bottom of the box.	Section 2-1 table 2-1

## A.2 Connectors

Table A-2 specifies the list of connectors for *T/X-DDC/AFE* external RF amplifier.


*Table A-2.* Connectors of T/X-DDC/AFE module.

Connector	description
JP1	RF-IN BNC connector for connection to external RF signal source.
JP2	RF-OUT BNC connector for connection to the RF-AIN input BNC connector of external cable set of digital radio receiver.
JP3	Power/control connector for connection to AUX I/O connector of external cable set of digital radio receiver DCM.

***pinout for JP3 power/control connector***

JP3 power/control connector of *T/X-DDC/AFE* is the industry-standard high-density DBH-15 15-pins male connector, which is compatible with connectors for PC VGA monitors. The compatible female plugs are available from multiple industry connector manufacturers.

Pinout for JP3 power/control connector for *T/X-DDC/AFE* is presented at fig.A-2, and description of signals is presented in table A-1.

*Fig. A-2.* Pinout for JP3 power/control connector of *T/X-DDC/AFE*.*Table A-1.* Signal description for JP3 power/control connector of *T/X-DDC/AFE*.

Signal name	description
AOUT-1 AOUT-2	DC voltage inputs for gain control.
GND	Ground.

+12v -12v	Power supply.
--------------	---------------